



Installation Instructions

Replacing An Existing Deadbolt


Models: **671 - Single Cylinder Deadbolts**
672 - Double Cylinder Deadbolts

NOTE: Install Cylinder with key removed & deadbolt fully extended



Template

Cut Along Dotted Line




Weslock

Installation Instructions New Door Preparation


Tools Required: Wood Chisel, Hammer, Phillips Head Screwdriver,
Installation Kit or 1" Diameter Boring Tool & 2-1/8" Diameter Boring Tool

Note: Use template on reverse for marking & drilling new door

Backset Description




A Mark Door




Use template to mark door about 44" from the floor.

B Drill 2-1/8" Hole




Drill a 2-1/8" diameter hole through face of door.

C Drill 1" Hole




Drill 1" diameter hole through to 2-1/8" hole.
For 1" deadbolt (models 671, 672, 496, & 499),
continue 1/2" deep into back side of 2-1/8" hole.

D Mark Jamb




With door closed, use a short pencil in the 1" edge hole to mark the bolt location in the door jamb.

E Drill Hole




Drill 1" diameter hole straight into door jamb deep enough to completely clear deadbolt when fully extended

F Chisel Strike Area



Vertically align strike on door jamb.
Mark around strike and chisel out area 1/16" deep or until strike fits flush.

G Install Strike



Insert strike and tighten wood screws.

Weslock

© 1995

Tulsa, Oklahoma

Part No. 09684